

Table of Contents

Chapter 1: Getting Started

Introduction	1-2
The Purpose of this Manual	1-2
Who Should Read this Manual	1-2
Where to Begin	1-2
Supplemental Manuals	1-2
How this Manual is Organized	1-3
Technical Assistance	1-3
DL305 System Components	1-4
<i>Direct</i> SOFT Programming for Windows™	1-4
Handheld Programmer	1-4
DL305 System Diagrams	1-4
<i>Direct</i>LOGIC™ Part Numbering System	1-8
Steps to a Successful System	1-10
Step 1: Review the Installation Guidelines	1-10
Step 2: Understand the CPU Setup Procedures	1-10
Step 3: Understand the I/O System Configurations	1-10
Step 4: Review the I/O Selection Criteria	1-10
Step 5: Determine the I/O Module Specifications and Wiring Characteristics	1-10
Step 6: Understand the System Operation	1-11
Step 7: Review the Programming Concepts	1-11
Step 8: Choose the Instructions	1-11
Step 9: Understand the Maintenance and Troubleshooting Procedures	1-11

Chapter 2: Installation and Safety Guidelines

Safety Guidelines	2-2
Plan for Safety	2-2
Safety Techniques	2-2
Orderly System Shutdown	2-3
System Power Disconnect	2-3
Panel Design Specifications	2-4
Environmental Specifications	2-6
Power	2-6
Agency Approvals	2-7
Enclosures	2-7
Component Dimensions	2-7
Component Dimensions Part 2	2-9
Base Mounting Dimensions	2-10
Installing Components in the Base	2-10
Base Wiring	2-11
Expansion Base Wiring	2-11

I/O Wiring	2-12
I/O Wiring Guidelines	2-12
Wiring the Different Module Types	2-13
 Chapter 3: DL330/DL330P/DL340 CPU Specifications	
Overview	3-2
DL330 CPU Features	3-2
DL330P CPU Features	3-2
DL340 CPU Features	3-2
CPU Hardware Features	3-2
CPU Specifications	3-3
Selecting CPU Memory Options	3-4
Internal Retentive Memory	3-4
External Program Storage	3-4
Volatile and Non-volatile Memory	3-4
Program Storage Memory Types (Internal)	3-5
Storing Programs on UVPROMs	3-6
Setting up the PROM Writer Unit	3-7
Copying a Program From the CPU RAM to a UVPROM	3-7
Copying a Program From the UVPROM to the CPU RAM	3-8
Comparing a Program From the UVPROM to the CPU RAM	3-8
Erasing a UVPROM	3-8
DL330/DL330P CPU Setup	3-9
Installing the UVPROM Option in the DL330 / DL330P CPU	3-9
Selecting Retentive Memory for the DL330 / DL330P	3-9
DL330/DL330P Networking	3-9
DL340 CPU Setup	3-10
Installing the optional UVPROM or EEPROM in the DL340 CPU	3-10
Selecting Retentive Memory for the DL340	3-11
DL340 Port Setup	3-12
DL340 Baud Rate Selection	3-12
DL340 Network Address Selection	3-12
DL340 RS232C Port (1 and 2) Pin Outs	3-13
DL340 Station Type Selection and Address Ranges	3-13
DL340 Selecting the Response Delay Time	3-13
DL340 Selecting Data Format (ASCII/HEX)	3-13
DL340 Selecting Parity for Port 2	3-13
Battery Backup	3-14
Memory Battery Backup	3-14
DL330, DL330P, DL340 CPU Battery Replacement	3-14
Installing the CPU	3-15
CPU Setup and System Functions	3-16
A Few Things to Know	3-16
What are Auxiliary Functions?	3-17
Connecting the Programming Devices	3-18
Changing the CPU Mode of Operation	3-20

Clearing the CPU Memory	3-21
CPU Checklist	3-21

Chapter 4: Bases, Expansion Bases, and I/O Configuration

Understanding I/O Numbering and Module Placement Rules	4-2
DL305 I/O Configuration History	4-2
Octal Numbering System	4-2
Fixed I/O Numbering	4-2
I/O Numbering Guidelines	4-3
Number of I/O Points Required for Each Module	4-3
I/O Module Placement Rules	4-4
DL330/DL330P Rules for 16 Point Modules	4-5
DL340 Rules for 16 Point Modules	4-6
Base Specifications and Wiring	4-7
Three Sizes of Bases	4-7
Bases and Maximum I/O Supported	4-8
Base Mounting Dimensions	4-8
Connecting the Power Supply	4-9
Expansion Base Power Supply Wiring Example	4-9
Base Specifications	4-10
Auxiliary 24VDC Output at Base Terminal	4-10
Power Supply Schematics	4-11
Using the Run Relay on the Base Power Supply	4-12
Installing CPUs and I/O Modules	4-13
Using Bases for Local or Expansion I/O Systems	4-14
Base Uses Table	4-14
Local/Expansion Connectivity	4-14
Connecting Expansion Bases	4-15
Setting the Base Switches	4-16
5 Slot Bases	4-16
10 Slot Base	4-16
Example I/O Configurations	4-17
16 Point I/O Allocation Example	4-17
Examples Show Maximum I/O Points Available	4-17
I/O Configurations with a 5 Slot Local CPU Base	4-18
Switch settings	4-18
5 Slot Base with 8 Point I/O	4-18
5 Slot Base with 16 Point I/O	4-18
5 Slot Base and 5 Slot Expansion Base with 8 Point I/O	4-19
5 Slot Base and 5 Slot Expansion Base with 16 Point I/O	4-19
5 Slot Base and Two 5 Slot Expansion Bases with 8 Point I/O	4-20
5 Slot Base and Two 5 Slot Expansion Bases with 16 and 8 Point I/O	4-20
I/O Configurations with an 8 Slot Local CPU Base	4-21
8 Slot Base with 8 Point I/O	4-21
8 Slot Base with 16 Point I/O	4-21
8 Slot Base and 5 Slot Expansion Base with 8 Point I/O	4-21
8 Slot Base and 5 Slot Expansion Base with 16 Point I/O	4-21

I/O Configurations with a 10 Slot Local CPU Base	4-22
Switch settings	4-22
Last Slot Address Range 100 to 107	4-22
Last Slot Address Range 700 to 707	4-22
10 Slot Expansion Base with 16 Point I/O	4-23
Configuration 1	4-23
Configuration 2	4-23
10 Slot Base and 5 Slot Expansion Base with 16 Point I/O	4-24
Expansion Addresses Depend on Local CPU Base Configuration.	4-25
10 Slot Base and 10 Slot Expansion Base with 8 Point I/O	4-25
10 Slot Base and 10 Slot Expansion Base with 16 Point I/O	4-25
Calculating the Power Budget	4-26
Managing your Power Resource	4-26
Auxiliary Base Power Source	4-26
Base Power Specifications	4-26
Module Power Requirements	4-27
Power Budget Calculation Example	4-30
Power Budget Calculation Worksheet	4-31

Chapter 5: I/O Module Selection & Wiring Guidelines

I/O Selection Considerations	5-2
I/O Module Selection	5-2
Sinking and Sourcing Circuits	5-2
DL305 Input Module Configuration Chart	5-3
DL305 Output Module Configuration Chart	5-3
Configuration #1 DL305 DC Current Sourcing Input Module	5-4
Configuration #2 DL305 DC Current Sinking/Sourcing Input Module	5-4
Configuration #3 DL305 DC Current Sinking Input Module	5-5
Configuration #4 DL305 AC/DC Input Module	5-5
Configuration #5 DL305 AC Input Module	5-6
Configuration #6 DL305 DC Current Sinking Output Module	5-7
Configuration #7 DL305 DC Current Sourcing Output Module	5-7
Configuration #8 DL305 AC/DC Current Sink/Source (Relay) Output Module	5-8
Configuration #9 DL305 AC Output Module	5-8
Solid State Field Device Wiring to DC Input Modules	5-9
NPN Field Device Example	5-9
PNP Field Device Example	5-9
Derating Characteristics	5-10
I/O Wiring Guidelines	5-11
General Considerations	5-11
Wiring the Different Module Types	5-11
Fuse Protection	5-12
External Fuse Example	5-12

Chapter 6: Discrete Input Modules

Discrete Input Module Identification and Terminology	6-2
Discrete Input Module Status Indicators	6-2
Color Coding of I/O Modules	6-2
Input Module Selection	6-2
Inputs Per Module	6-3
Commons Per Module	6-3
Input Voltage Range	6-3
Peak Voltage	6-3
AC Frequency	6-3
ON Voltage Level	6-3
OFF Voltage Level	6-3
Input Current	6-3
Input Impedance	6-3
Minimum ON Current	6-3
Maximum OFF Current	6-3
Base Power Required	6-3
OFF to ON Response	6-3
ON to OFF Response	6-3
Terminal Type	6-3
Status Indicators	6-3
Weight	6-3
D3-08ND2, 24 VDC Input Module	6-4
D3-16ND2-1, 24 VDC Input Module	6-5
D3-16ND2-2, 24 VDC Input Module Module	6-6
D3-16ND2F, 24 VDC Fast Response Input Module	6-7
F3-16ND3F, TTL/24 VDC Fast Response Input Module	6-8
D3-08NA-1, 110 VAC Input Module	6-10
D3-08NA-2, 220 VAC Input Module	6-11
D3-16NA, 110 VAC Input Module	6-12
D3-08NE3, 24 VAC/DC Input Module	6-13
D3-16NE3, 24 VAC/DC Input Module	6-14
D3-08SIM, Input Simulator	6-15

Chapter 7: Discrete Output Modules

Discrete Output Module Identification and Terminology	7-2
Discrete Output Module Status Indicators	7-2
Color Coding of I/O Modules	7-2
Output Modules Selection	7-2
Outputs Per Module	7-3
Commons Per Module	7-3
Operating Voltage	7-3
Output Type	7-3
Peak Voltage	7-3

AC Frequency	7-3
ON Voltage Drop	7-3
Maximum Current (Resistive)	7-3
Maximum Leakage Current	7-3
Maximum Inrush Current	7-3
Minimum Load	7-3
Base Power Required	7-3
OFF to ON Response Time	7-3
ON to OFF Response Time	7-3
Terminal Type	7-3
Status Indicators	7-3
Fuses	7-3
Relay Life	7-3
Weight	7-3
Relay Arc Suppression - DC and AC Applications	7-4
FL305 High Current Relay Output Module Arc Suppression	7-4
Resistor and Capacitor Selection	7-4
Resistor Tolerance	7-4
Peak Voltage and Current	7-4
Adding Contact Protection	7-4
Resistor and Capacitor Nomogram	7-5
D3-08TD1, 24 VDC Output Module	7-6
D3-08TD2, 24 VDC Output Module	7-7
D3-16TD1-1, 24 VDC Output Module	7-8
D3-16TD1-2, 24 VDC Output Module	7-9
D3-16TD2, 24 VDC Output Module	7-10
D3-04TAS, 110-220 VAC Output Module	7-11
F3-08TAS, 250 VAC Isolated Output Module	7-12
F3-08TAS-1, 125 VAC Isolated Output Module	7-13
D3-08TA-1, 110-220 VAC Output Module	7-14
D3-08TA-2, 110-220 VAC Output Module	7-15
F3-16TA-2, 20-125 VAC Output Module	7-16
D3-16TA-2, 110-220 VAC Output Module	7-17
D3-08TR, Relay Output Module	7-18
F3-08TRS-1, Relay Output Module	7-19
F3-08TRS-2, Relay Output Module	7-20
D3-16TR, Relay Output Module	7-21
 Chapter 8: System Operation	
Introduction	8-2
CPU Operating System	8-3
DL305 CPU Operational Flow Chart	8-3

Initial Mode Setting and Memory Initialization	8-4
Flow Chart for Initial Mode Setting (#1)	8-4
Memory Initialization	8-5
Program Mode Operation	8-6
Run Mode Operation	8-7
Update I/O Points	8-8
Service Peripherals	8-9
Service for Monitoring and Forcing Operations	8-10
Solve Application Program	8-12
I/O Response Time	8-14
Is Timing Important for Your Application?	8-14
Normal Minimum I/O Response	8-14
Normal Maximum I/O Response	8-15
Improving Response Time	8-15
CPU Scan Time Considerations	8-16
DL330 / DL330P Scan Calculation	8-16
DL340 Scan Calculation	8-17
Application Program Execution	8-18
Memory Map	8-19
Octal Numbering System	8-19
Two Basic Memory Types: Discrete and Word	8-19
R Memory Locations for Discrete Memory Areas	8-20
I/O Points	8-20
Control Relays	8-21
Timers and Timer Status Bits (T Data type)	8-22
Counters and Counter Status Bits (CT Data type)	8-22
Counter Current Values (R Data Type)	8-22
Data Registers (R Data Type)	8-23
Stages (S Data type)	8-23
Shift Registers	8-24
Special Relays	8-24
Special Registers (R Data Type)	8-24
DL305 Aliases	8-25
DL330 Memory Map	8-26
DL330P Memory Map	8-27
DL340 Memory Map	8-28
I/O Point Bit Map	8-29
Control Relay Bit Map	8-30
Special Relays	8-32
Timer / Counter Registers and Contacts	8-33
External Timer/Counter Setpoint Unit	8-33
Data Registers	8-34
Stage Control / Status Bit Map	8-36
Shift Register Bit Map	8-37
Special Registers	8-38

Chapter 9: Programming Basics

Introduction	9-2
Using Boolean Instructions	9-3
END Statement	9-3
Simple Rungs	9-3
Normally Closed Contact	9-3
Contacts in Series	9-4
Midline Outputs	9-4
Parallel Elements	9-4
Joining Series Branches in Parallel	9-5
Joining Parallel Branches in Series	9-5
Comparative Boolean	9-5
Combination Networks	9-6
Boolean Stack	9-6
Using Timers	9-8
Using Counters	9-9
Using the Accumulator	9-10
Copying Data to and from the Accumulator	9-10
Changing the Accumulator Data	9-11
Accumulator Operations	9-12

Chapter 10: RLL^{PLUS} Programming Basics

Introduction	10-2
An Example Machine	10-3
Machine Operation	10-3
Machine Flowchart	10-3
An RLL Solution	10-4
An RLL^{PLUS} Solution	10-5
Stage Instruction Execution	10-6
Stage Instruction Numbering	10-6
A Few Simple Rules for Execution	10-7
Activating Stages	10-8
Using Initial Stages	10-8
Using Jump Instructions	10-9
Using Set Instructions with Stages	10-10
Power Flow Transitions	10-11
Using Outputs in Stages	10-12
Setting Outputs with the SET Instruction	10-12
Using the OUT Instruction	10-13
Latching Outputs with Stages	10-14
Using Timers and Counters in Stages	10-15
Time Based Transitions	10-15
Using Counters	10-16
Using Data Instructions in Stages	10-17

Using Comparative Contacts in Stages	10-18
Parallel Branching Concepts	10-19
Branching Methods	10-19
Joining Parallel Branches	10-20
Using Stage Bits as Contacts	10-21
Stage Contact Example	10-22
Unusual Operations in Stages	10-23
Using the Same Output Multiple Times	10-23
Using a Set Out Reset (SET OUT RST) Instruction	10-24
Output Placement	10-24
Two Ways to View RLL^{PLUS} Programs	10-25
<i>DirectSOFT</i> Stage View	10-25
<i>DirectSOFT</i> Ladder View	10-25
Designing a Program Using RLL^{PLUS} Instructions	10-27
Use <i>DirectSOFT</i> to Save Time	10-27
Step 1: Design a Top-level Flowchart	10-28
Step 2: Add Flowchart Transitions	10-29
Step 3: Add Actions	10-30
Step 4: Add Conditions for Actions	10-31
Step 5: Add Alarm or Monitoring Operations	10-32
Step 6: Determine Stage Numbering	10-33
Step 7: Assign I/O Addresses	10-35
Step 8: Enter the Program	10-36

Chapter 11: Instruction Set

Introduction	11-2
Store (STR)	11-4
Store Not (STR NOT)	11-4
Store Timer (STR TMR) DL330/340 Only	11-5
Store Not Timer (STR NOT TMR) DL330/340 Only	11-5
Store Counter (STR CNT) DL330/340 Only	11-6
Store Not Counter (STR NOT CNT) DL330/340 Only	11-6
Or (OR)	11-7
Or Not (OR NOT)	11-7
Or Timer (OR TMR) DL330/340 Only	11-8
Or Not Timer (OR NOT TMR) DL330/340 Only	11-8
Or Counter (OR CNT) DL330/340 Only	11-9
Or Not Counter (OR NOT CNT) DL330/340 Only	11-9
And (AND)	11-10
And Not (AND NOT)	11-10
And Timer (AND TMR) DL330/340 Only	11-11
And Not Timer (AND NOT TMR) DL330/340 Only	11-11
And Counter (AND CNT) DL330/340 Only	11-12
And Not Counter (AND NOT CNT) DL330/340 Only	11-12
And Store (AND STR)	11-13
Or Store (OR STR)	11-13
Out (OUT)	11-15
Set (SET) DL330/340 Only	11-16
Reset (RST) DL330/340 Only	11-16

Set Out (SET OUT)	11-17
Set Out Reset (SET OUT RST)	11-18
Store If Equal (STR) DL330/DL340 Only	11-19
Store Not If Equal (STR NOT) DL330/DL340 Only	11-19
Or If Equal (OR) DL330/DL340 Only	11-20
Or Not If Equal (OR NOT) DL330/DL340 Only	11-20
And If Equal (AND) DL330/DL340 Only	11-21
And Not If Equal (AND NOT) DL330/DL340 Only	11-21
Timer (TMR) DL330/DL340 Only	11-22
Counter (CNT) DL330/DL340 Only	11-23
Shift Register (SR) DL330/340 Only	11-24
Data Store DSTR (F50)	11-25
Data Out DOUT (F60)	11-25
Data Store 1 DSTR (F51)	11-26
Data Out 1 DOUT (F61)	11-26
Data Store 2 DSTR (F52)	11-27
Data Out 2 DOUT (F62)	11-27
Data Store 3 DSTR (F53)	11-28
Data Out 3 DOUT (F63)	11-28
Data Store 5 DSTR (F55)	11-29
Data Out 5 DOUT (F65)	11-29
Data And DAND (F75)	11-30
Data Or DOR (F76)	11-31
Compare CMP (F70)	11-32
Add ADD (F71)	11-34
Add Example	11-35
Subtract SUB (F72)	11-36
Subtract Example	11-37
Multiply MUL (F73)	11-38
Multiply Example	11-39
Divide DIV (F74)	11-40
Divide Example	11-41
Shift Left SHFL (F81)	11-42
Shift Right SHFR (F80)	11-43
Number Conversion Instructions	11-44
Encode ENCOD (F83)	11-44
Decode DECOD (F82)	11-46
Binary BIN (F85)	11-47
Binary Coded Decimal BCD (F86)	11-48
Invert INV (F84)	11-49
Program Control Instructions	11-50
Master Control Set (MCS) and Master Control Reset (MCR) DL330/DL340 only	11-50
Understanding Master Control Relays	11-50
MCS/MCR Example	11-51
Network Instructions	11-52
Read from Network RX (F952) DL340 Only	11-52
Write to Network WX (F953) DL340 Only	11-54
Message Instructions	11-56
Fault FAULT (F20)	11-56

Chapter 12: RLL^{PLUS} Instruction Set

Introduction	12-2
Initial Stage (ISG) DL330P Only	12-3
Stage (SG) DL330P Only	12-3
Jump (JMP) DL330P Only	12-5
Not Jump (NOT JMP) DL330P Only	12-5
Store Stage (STR SG) DL330P Only	12-7
Store Not Stage (STR NOT SG) DL330P Only	12-7
Or Stage (OR SG) DL330P Only	12-8
Or Not Stage (OR NOT SG) DL330P Only	12-8
And Stage (AND Stage) DL330P Only	12-9
And Not Stage (AND NOT SG) DL330P Only	12-9
Set (SET) DL330P Only	12-10
Reset (RST) DL330P Only	12-10
Set Stage (SET SG) DL330P Only	12-11
Reset Stage (RST SG) DL330P Only	12-11
Comparative Boolean Instructions	12-12
Store If Greater Than or Equal To Timer (STR TMR) DL330P Only	12-12
Store Not If Greater Than Timer (STR NOT TMR) DL330P Only	12-12
Store If Greater Than or Equal To Counter (STR CNT) DL330P Only	12-13
Store Not If Greater Than Counter (STR NOT CNT) DL330P Only	12-13
Or If Greater Than or Equal To Timer (OR TMR) DL330P Only	12-14
Or Not If Greater Than Timer (OR NOT TMR) DL330P Only	12-14
Or If Greater Than or Equal To Counter (OR CNT) DL330P Only	12-15
Or Not If Greater Than Counter (OR NOT CNT) DL330P Only	12-15
And If Greater Than or Equal To Timer (AND TMR) DL330P Only	12-16
And Not If Greater Than Timer (AND NOT TMR) DL330P Only	12-16
And If Greater Than or Equal To Counter (AND CNT) DL330P Only	12-17
And Not If Greater Than Counter (AND NOT CNT) DL330P Only	12-17
Timer, Counter, and Shift Register Instructions	12-18
Timer (TMR) DL330P Only	12-18
Counter (CNT) DL330P Only	12-19
Reset Counter (RST) DL330P Only	12-20
Shift Register (SR) DL330P Only	12-21

Chapter 13: Maintenance and Troubleshooting

Maintenance	13-2
CPU Indicators	13-3
Power Indicator	13-4
RUN Indicator	13-6
CPU Indicator	13-6
BATT Indicator	13-6
Expansion Base Power	13-7
Testing Output Points	13-8
I/O Module Troubleshooting	13-10

Noise Troubleshooting	13-11
Machine Startup and Program Troubleshooting	13-12

Appendix A: Quick Start Example

Step 1: Unpack the DL305 Equipment	A-2
Step 2: Configure the 5-slot Base as the Local CPU Base	A-3
Step 3: Install the CPU and I/O Modules	A-3
Step 4: Wire the I/O Modules to the Field Devices	A-4
Step 5: Remove the Terminal Strip Access Cover	A-4
Step 6: Connect the Power Wiring	A-5
Step 7: Connect the Handheld Programmer	A-6
Step 8: Connect the Power Source	A-7
Step 9: Enter the Example Program	A-7

Appendix B: DL305 Error Codes

Appendix C: Instruction Execution Times

Introduction	C-2
Data Registers	C-2
I/O Data Registers	C-2
How to Read the Tables	C-3
DL330 Instruction Execution Times	C-4
Basic Input Instructions	C-4
Output Type Instructions	C-4
Timer, Counters, and Shift Registers	C-5
Data Operations	C-5
DL330P Instruction Execution Times	C-6
Basic Input Instructions	C-6
Output Type Instructions	C-6
Timer, Counters, and Shift Registers	C-6
Stage Instructions	C-7
Data Operation Instructions	C-7
DL340 Instruction Execution Times	C-8
Basic Input Instructions	C-8
Comparative Contacts	C-8
Output Type Instructions	C-8
Timer, Counters, and Shift Registers	C-9
Data Operation Instructions	C-9

Appendix D: DL305 Product Weight Tables

Product Weight Table	D-2
----------------------------	-----

Index