

REPLACEMENT PARTS



In This Chapter...

Replacement Parts Overview	9-2
Replacement Parts	9-2
Customizing the Function Keys Insert Label	9-3

Replacement Parts Overview

Part Number	Description
EA-MG-BZ2-BRK	Replacement mounting clip for <i>C-more</i> 6" Micro-Graphic panel and keypad bezels (pk of 8)
EA-MG-DC-CON	Replacement adapter DC power connector (pk of 5)
EA-MG6-S6ML-GSK	Replacement mounting gasket for <i>C-more</i> 6" Micro-Graphic panels
EA-MG6-BZ2-GSK	Replacement mounting gasket for <i>C-more</i> 6" Micro-Graphic keypad bezels EA-MG-BZ2(P)
EA-MG-S6ML-FKL	Replacement function key label insert for <i>C-more</i> 6" Micro-Graphic panels (pk of 5; 3 blank, 1 F1-F5 for landscape, 1 F1-F5 for portrait)
EA-6-COV2	Clear Screen Overlay (pk of 3)

Replacement Parts

Mounting Clips for 6" panel or bezel

Part No. EA-MG-BZ2-BRK



(pk of 8)

DC Power Connector

Part No. EA-MG-DC-CON



(pk of 5)


Panel Gasket

Part No. EA-MG6-S6ML-GSK



Function Keys Label Inserts

Part No. EA-MG6-S6ML-FKL



(pk of 5; 3 blank,
1 F1-F5 for landscape,
1 F1-F5 for portrait)

Keypad Bezel Gasket

Part No. EA-MG6-BZ2-GSK



Clear Screen Overlay

EA-6-COV2



(pk of 3)

9

Customizing the Function Keys Insert Label

Step 1 - Remove existing function key label insert using a small tool such as jeweler's screw driver.



Step 3 - If desired, print and apply self adhesive labels to the blank insert.



Step 2 - Remove the protective film from the blank key label insert.



Step 4 - Install the new insert into the slot in the side of the panel and lock tab into place.

