

# TABLE OF CONTENTS



---

<b>Chapter 1: Getting Started</b> .....	<b>1-1</b>
Manual Overview .....	1-2
Overview of this Publication .....	1-2
Technical Support .....	1-2
Special Symbols .....	1-2
Overview of the EZ-Ethernet Card .....	1-2
Operating System .....	1-3
Packing List .....	1-3
Minimum Required Hardware .....	1-4
Minimum Required Software/Firmware .....	1-4
Typical EZ-Ethernet System .....	1-5
Installing the EZ-Ethernet Card .....	1-6
<b>Chapter 2: Setting Up &amp; Using the EZ-Ethernet</b> ..	<b>2-1</b>
Setting Up Your EZ-Ethernet System .....	2-2
DIP Switch Settings .....	2-2
Diagnostic LEDs .....	2-4
Status Indicator .....	2-4
Link Good Indicator .....	2-4
Link Active Indicator .....	2-4
Error Indicator .....	2-4
Tutorials .....	2-5
Tutorial A: First Time Connection .....	2-5
Tutorial B: Adding PLCs to Your Project .....	2-15
Tutorial C: Adding a Second EZTouch Panel .....	2-20
EZ-Ethernet Firmware Upgrade Instructions .....	2-24
The EZ-Touch Panel Configuration Window .....	2-26
The NetEdit Window .....	2-27

**Appendix A: Specifications & Error Codes . . . . .A-1**  
EZ-Ethernet Card Specifications . . . . .A-2  
Ethernet Cable . . . . .A-3  
EZ-Ethernet Error Code Descriptions . . . . .A-3

**Appendix B: EZ-ETHERPLUS . . . . .B-1**  
Introduction . . . . .B-2  
Configuring MODBUS/TCP Nodes . . . . .B-3  
Things to Remember . . . . .B-9