



# TABLE OF CONTENTS

---

## Chapter 1: Getting Started

<b>Introduction</b> .....	<b>1-2</b>
The Purpose of This Manual .....	1-2
Supplemental Manuals .....	1-2
Technical Support .....	1-2
<b>Conventions Used</b> .....	<b>1-3</b>
Key Topics for Each Chapter.....	1-3
<b>Product Overview</b> .....	<b>1-4</b>
<b>Quick Start Steps</b> .....	<b>1-5</b>
Step 1 – Unpack and Inspect.....	1-5
Step 2 – Install Optional Hardware Accessories.....	1-6
Step 3 – Become Familiar with Available Communication Ports.....	1-7
Step 4 – Install the Programming Software and Develop a Project .....	1-8
Step 5 – Connect HMI to Computer .....	1-9
Step 6 – Provide Power to the HMI .....	1-10
Step 7 – Access the EA9-RHMI Setup Screens .....	1-13
Step 8 – Choose HMI to Device Cable.....	1-14
Step 9 – Connect HMI to PLC .....	1-17

## Chapter 2: Specifications

<b>Specifications</b> .....	<b>2-2</b>
<b>Dimensions</b> .....	<b>2-4</b>
Inches [mm].....	2-4
<b>Communication Ports and Memory Expansion</b> .....	<b>2-5</b>
<b>Compatible Touch Screen Monitors</b> .....	<b>2-7</b>
<b>Handling External Memory Devices</b> .....	<b>2-8</b>
Writing to External Memory Devices .....	2-8

## Table of Contents

---

1

Memory Device Formatting.....	2-8
Minimizing Data Errors.....	2-9
Monitoring Available Memory .....	2-9
File Name Limitations.....	2-10
Power Loss Retention .....	2-10

### Chapter 3: Accessories

Accessories Overview.....	3-2
EA-ECOM Ethernet Communication Module.....	3-3
D-SUB 15-pin to Terminal Block Adapter .....	3-4
SD Card .....	3-5
USB FLASH Drive .....	3-5

### Chapter 4: Installation and Wiring

Safety Guidelines .....	4-2
Introduction.....	4-3
Mounting .....	4-4
DIN Rail Mounting .....	4-4
Panel Mounting.....	4-4
Mounting Clearances .....	4-5
Wiring Guidelines .....	4-6
Agency Approvals.....	4-6
Providing Power to the HMI.....	4-7
C-more LED Status Indicators.....	4-8
Reset Button.....	4-9
RUN/STOP switch.....	4-9

### Chapter 5: System Setup Screens

Introduction.....	5-2
Accessing the System Setup Screens .....	5-3
With no project loaded .....	5-3
With project loaded.....	5-4
Using RHMI USB Remote.....	5-5

System Setup Screens – Enable Password in Software .....	5-8
System Setup Screens Flowchart .....	5-14
Main Menu.....	5-15
Information Menu .....	5-16
Setting Menu .....	5-20
Test Menu .....	5-26
Memory Menu .....	5-36

## Chapter 6: PLC Communications

Introduction.....	6-2
<i>Direct</i> LOGIC PLCs Password Protection .....	6-2
PLC Protocols .....	6-3
<b>PLC Communication Cables &amp; Wiring Diagrams.....</b>	<b>6-5</b>
AutomationDirect PLCs RS-232C Serial.....	6-7
AutomationDirect PLCs RS-422A/RS-485A.....	6-10
<i>Direct</i> LOGIC Universal Isolated Network Adapter, p/n FA-ISOCAN: .....	6-16
<i>Direct</i> LOGIC Universal Converter, p/n F2-UNICON: .....	6-17
RS-422A/RS-485A Multi-Drop Wiring Diagram Examples .....	6-18
Allen-Bradley .....	6-22
GE.....	6-27
GE VersaMax Micro .....	6-27
Mitsubishi.....	6-28
Omron .....	6-30
Modicon Modbus RS-232.....	6-31
Modicon Micro Series.....	6-31
Modicon Modbus with RJ45.....	6-31
Siemens.....	6-32

## Chapter 7: Maintenance

Project Backup .....	7-2
Check Operating Environment .....	7-2
Check Operating Voltage .....	7-2
Check Status Indicators .....	7-2
Check Physical Conditions.....	7-3

Run Tests under System Setup Screens.....	7-3
Check Memory Usage .....	7-3
Check Error Log .....	7-4
Check Project Functionality .....	7-4
Checks from <i>C-more</i> Programming Software.....	7-5
<b>Notes:</b> .....	<b>7-6</b>

## Chapter 8: Troubleshooting

Common Problems .....	8-2
Troubleshooting Flow Chart.....	8-3
HMI Does Not Power Up.....	8-4
<i>C-more</i> LED Status Indicators.....	8-5
General Errors and Warnings .....	8-6
Display is Blank .....	8-7
No User Program .....	8-8
Touch Screen Does Not Work .....	8-9
Touch Screen Calibration is Inverted .....	8-9
Firmware Recovery Tool .....	8-10
No System Found.....	8-11
No Communications Between Panel and PC (Personal Computer) via USB .....	8-12
USB Driver Troubleshooting .....	8-14
No Communications Between Panel and PC (Personal Computer) via Ethernet .....	8-16
No Communications Between Panel and PLC .....	8-21
IP Address in System Setup Screens Displays 0.0.0.0 .....	8-24
Difficulty Connecting to the Panel over the Internet (Web Server and Remote Access Features) .....	8-25
PLC Protocol Error Codes .....	8-26
HMI Runtime Errors.....	8-27
Panel Constantly Displays “Initializing” when Powering Up.....	8-28
Data Not Logging Problems.....	8-28
Electrical Noise Problems.....	8-29
Touch Screen Not Working .....	8-29

## Chapter 9: Replacement Parts

Replacement Parts Overview .....	9-2
3-wire Communications Terminal Block – EA9-3TB.....	9-3
DC Power Connector Replacement – C0-4TB.....	9-3

## Appendix A: HMI and PLC Error Code Tables

Introduction.....	A-2
<i>C-more</i> HMI Error Code Table .....	A-3
<i>Direct</i> LOGIC – Panel Error Code PLC-499 Explanation .....	A-5
<i>Direct</i> LOGIC K-Sequence Protocol – PLC Error Code Table.....	A-5
<i>Direct</i> LOGIC <i>Direct</i> NET Protocol – PLC Error Codes.....	A-5
Modbus Protocols Error Code P499 Explanation .....	A-6
AutomationDirect CLICK .....	A-6
AutomationDirect <i>Direct</i> LOGIC - Modbus (Koyo).....	A-6
Modicon Modbus RTU .....	A-6
Entivity Modbus RTU.....	A-6
<i>Direct</i> LOGIC ECOM Protocol – PLC Error Codes.....	A-6
Productivity Error Code P499.....	A-7
AutomationDirect Do-More Error Codes.....	A-8
Allen-Bradley – Panel Error Code PLC-499 Explanation .....	A-9
Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables .....	A-10
Allen-Bradley EtherNet/IP Protocol – Panel Error Code PLC-496, 497 and 498 Explanation .....	A-12
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, and FlexLogix .....	A-13
Allen-Bradley – Micro800 Serial and EtherNet/IP Tag Based PLC Error Code Tables .....	A-17
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables SLC, MicroLogix and ENI.....	A-21
Generic EtherNet IP Protocol – PLC Error Codes .....	A-26
GE 90-30 – Panel Error Code PLC-499 Explanation.....	A-27
GE 90-30 SNPX Protocol – PLC Error Code Tables.....	A-28

Mitsubishi FX Protocol – PLC Error Codes.....	A-37
Omron – Panel Error Code PLC-499 Explanation .....	A-37
Omron Host Link Protocol – PLC Error Code Table .....	A-38
Omron FINS Protocol – PLC Error Code Table .....	A-39
Omron – Panel Error Code P495 Explanation .....	A-42
Omron CS/CJ FINS Ethernet Protocol – PLC Error Code Table.....	A-43
Siemens – Panel Error Code P499 Explanation.....	A-44
Siemens PPI Protocol – PLC Error Code Table.....	A-45
Siemens ISO over TCP Protocol – PLC Error Code Table .....	A-46

### Appendix B: HMI Runtime Errors

Introduction.....	B-2
Runtime Errors.....	B-3
Log File Naming.....	B-4

### Appendix C: Security Considerations for Control Systems Networks

Security Considerations for Control Systems Networks.....	C-2
---	-----